

Grow Bed Extension Assembly Instructions

3' x 6' Grow Bed and Extension Instructions

If you purchased a 3 x 6 Grow Bed, note that it includes a 3 x 3 Grow Bed and Grow Bed Extension Kit. First assemble the 3' x 3' Bed, assembling only three sides, then follow this instruction sheet to add the extension.

Parts included:

Side Panels (2)
Steel U-Brace (1)
Connector Plates (2)
Nuts (8)
Bolts (8)

Tools needed:

Electric drill, screwdriver, pencil

Step 1. If you are extending an existing Grow Bed, remove a Panel from the side you want to extend.

Step 2. Place the two Extension Side Panels on the ground, interlocking them with the original bed Panels. Position a Connector Plate where the panels

meet as shown (Figure 1). Use a pencil to mark each panel through the 4 holes in the Plate on each side.

Step 3. Remove the Connector Plates and drill holes through the four marks on each Panel. Use a drill bit slightly larger than 6mm (1/4 inch) to ensure that the bolts will pass through the holes.

Step 4. Position the Connector Plates on the Panels. Use a screwdriver to attach the Connector Plates with the nuts and bolts provided (Figure 1).

Step 5. Lift the Bed and place the Steel U-Brace through the horizontal links created by the interlocking Panels (Figure 1).

Step 6. Place the Corner Pins from the original Grow Bed into the corners of the extended Grow Bed. The assembly is now finished.

