

Paper Pot Maker

Parts Included

Handle
Base

Required Material

Sheets of newspaper



Step 1. Tear a strip of newspaper about 3" wide x 12" long. Roll the paper around the Handle, leaving about 1" extending beyond the bottom.



Step 2. Tuck the inch of overhanging paper into the bottom of the Handle.



Step 3. Place the Handle onto the the Base and twist it gently a few times.



Step 4. Remove the finished paper pot from the Handle. Place it on a tray and fill with germinating mix.



Tip: Experiment with different paper pot heights by making your newspaper strips wider. You can also make the walls thicker by using longer strips of newspaper.

