

Exeter Wall Trellis, Small & Large

Hanging Hardware

Screw and anchors are not included since the type of hardware you need will depend on the type of wall you're installing it to. **NOTE:** Remember to include the weight of your plants when choosing hardware.

Installing on a Wall

Install two brackets at the height you want the bottom of your Trellis to sit. They should be 12-13" apart on the small size and 28-30" apart on the large size. Make sure the hooks are facing up and sit the trellis on top of them. Attach the remaining wall brackets so the hooks are supporting the top of the trellis.

The powder-coated steel Trellis is weather-resistant and can be left outdoors year-round. However, if the finish is nicked or scratched, use an exterior-grade metal paint to prevent rust.

8% of our profits go back to our communities.

Learn more at gardeners.com/FORCE-FOR-GOOD